



Cab Liner Installation For Center Door

Please read all instructions prior to installation.

The installation of Door Guard's elevator cab liner requires only the ratchet tool provided. Successful installation does require placing each section in the elevator in proper sequence as described below. Keep all sections folded until they are placed inside the elevator cab. All components are customized for a specific elevator and individually labeled. **Many components are labeled for the "left" and "right" side of the cab. Your orientation for the left and right side will be when you are inside the cab facing the lobby entrance (see Elevator Cab Configuration on Page 2).**

Step 1 Rear Wall Liner

Place the Rear Wall Liner inside the cab while still folded. Unfold the Rear Wall Liner and position it against the rear cab wall, centering it between the two side walls. If provided, install Rear Wall Stabilizer, on the top edge of the wall panel. **If you have a split wall, install only the Rear Bottom panel at this time and proceed to Step 2.**

Step 2 Button Panels & Header

- A. Position the Right Front Button Panel, Left Front Button Panel, and Interior Front Header inside the elevator. Lean both Left and Right Front Button Panels against the interior jambs/COP. Be sure the Locking Plates are disengaged per Step 1 of the Locking Plate Instructions.
- B. Slide the Interior Front Header over the top of the Left and Right Front Button Panels. Position the Left Front Button Panel firmly against the interior jamb/COP. Position the Right Front Button Panel firmly against the interior jamb/COP. Engage the Locking Plates per Steps 2 and 3 of the Locking Plate instructions.

Step 3 Left and Right Side Wall Liners

- A. Place the Left Side Wall Liner inside the cab while still folded. Be sure the Locking Plates are disengaged per Step 1 of the Locking Plate Instructions.
- B. Unfold the Left Side Wall Liner and position it against the left cab wall ensuring it is centered between the Rear Wall Liner and the Left Front Button Panel. If provided, install Left Side Wall Stabilizer on the top edge of the wall panel. Engage the Locking Plates per Steps 2 and 3 of the Locking Plate instructions. **If you have a split wall, install only the Left Bottom panel at this time and proceed to C.**
- C. Place the Right Side Wall Liner inside the cab while still folded. Be sure the Locking Plates are disengaged per Step 1 of the Locking Plate Instructions.


D. Unfold the Right Side Wall Liner and position it against the right cab wall ensuring it is centered between the Rear Wall Liner and the Right Front Button Panel. If provided, install Right Side Wall Stabilizer on the top edge of the wall panel. Engage the Locking Plates per Steps 2 and 3 of the Locking Plate instructions. **If you have a split wall, install only the Right Bottom panel at this time and proceed to Step 4.**

Step 4 Install Top panels for the Rear and Side Walls in the same order as Bottom Panels.

NOTE: Upon installation of side walls, you will note approximately a 1 inch gap between the side wall and either the button panel or rear wall adjacent to the locking plate. This 1 inch gap is designed to facilitate installation and de-installation of the Cab Liner.

If ordered, you are now ready to install the three-piece Door Liner using the enclosed installation instructions.

Elevator Cab Configuration



NOTE: Each Door Guard Cab Liner is fabricated to the exact cab dimensions and configuration of the elevator for which it was intended. This Cab Liner can only be used in elevators with the exact same model configuration and dimensions. Do not attempt to use your Cab Liner in an elevator using a different dimensional "foot print" as it will not protect the elevator interior as intended and you may damage your Cab Liner.

We strongly recommend storage of your panels in a vertical or horizontal position. **TO PREVENT BOWING, DO NOT LEAN PANELS AGAINST WALLS.** Panels should be stored at temperatures between 60 and 80 degrees Fahrenheit.

WARRANTY

One (1) year manufacturer's warranty indicating both cab liner and door liner is free of defects in material and workmanship. Warranty will not cover normal wear and tear, damage incurred during transportation, installation, de-installation, nor Locking Plate compression exceeding 70 pounds, or if not stored in accordance with manufacturer's recommendations as described in all installation instruction sheets.

**Door Guard Inc., Pittsburgh, PA 15205
 Phone 724 695 8936, Fax 724 695 8937
 email: sales@doorguardinc.com
 Website: www.doorguardinc.com
 U.S. Patent 61366251**